BRAKE FLUID TESTER

⚠ CAUTIONS:

- Always wear eye protection. If brake fluid contacts eyes, flush with water immediately and seek medical attention.
- Brake fluid is poisonous do not ingest. If you do ingest brake fluid, seek medical attention immediately.
- Always use new brake fluid from sealed container when bleeding hydraulic system.
- Do not allow brake fluid to contact vehicle paint. Wash with water immediately if brake fluid gets on paint.
- Never operate vehicle if you are in doubt of the effectiveness of the braking system. A firm brake pedal is required before you can operate the vehicle.
- Before use, read and understand all warnings, safety precautions, and instructions as outlined in the vehicle manufacturer's service manual. It is beyond the scope of this manual to properly describe the correct procedure and test data for each vehicle.
- The manufacturer declines any and all responsibility for damage to vehicles or components if said damage is the result of unskillful handling by the operator or of failure to observe the basic safety rules set forth in the instruction manual.

Operation:

1. Remove the cap and press the "power" button to turn on. If the light does not come on, check the battery and change if necessary.
2. Press the "switch" button to change the type of brake fluid.
3. Dip the tester into the brake fluid making sure the two metal probes are fully immersed. It will take about 1 second to measure the fluid. The tester will automatically shut off after 20 seconds.

   LED indications:

   - Green: Battery OK.

   - Yellow: Fluid contains less than 1% of water

   - Yellow/Yellow: Fluid contains less than 2% of water

   - Yellow/Yellow/Red: Fluid contains about 3% of water, change the brake fluid

   - Yellow/Yellow/Red/Red: Fluid contains about 4% of water, dangerous! Change the brake fluid immediately.

Limited Lifetime Warranty

If for as long as you own this OEMTOOLS® product you find any defect in material or workmanship, through normal usage and not including standard wear, either return it to the place of purchase, or send it to OEMTOOLS for repair or replacement at our discretion. In order to obtain this service send your tool and proof of purchase, transportation pre-paid, to OEMTOOLS Q.A. Dept., 3580 E. Raines Rd. #3, Memphis, TN 38118. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. Please see our website for full warranty information.

OEMTOOLS® Company, Mineola, NY 11501 / Made In Taiwan / www.oem-tools.com

01/16
2016 OEMTOOLS